

Open instruNet World Window from within your program

The following line of code will open the instruNet World window from your program: "Open_instruNet_Window_Easy(iNetCM_OpenWindow_Network);". This can be useful at debugging since it enables one to view the current state of the instruNet settings.

Turning off Calibration

The following C code turns off the calibration options:

```
iNetChannelAddr calOptions;  
iNetError e = iNetErr_None; Boolean chanExists;  
  
// Specify Driver Options area  
chanExists = LoadChannelAddress( &calOptions, netNum_DRIVER /* 0 */, deviceNum_DRIVER /* 0 */,  
moduleNum_1stModule /* 1 */, driver_ChanNum_RecordOptions /* 3 */);  
  
// Set "Calibration on Start"(full hardware calibration when Digitze begins) to off  
e = SetField_int32(&calOptions, sgt_CalOptions /* -21 */, fldNum_CalOptions_CalOnStart,  
ion_gOnOffPopup_Off);  
  
// Set "Calibration on Warm" (full hardware calibration 10min and 25min after reset) to off  
e = SetField_int32(&calOptions, sgt_CalOptions /* -21 */, fldNum_CalOptions_CalOnWarm, ion_gOnOffPopup_Off);  
  
// Set "Auto Calibration Rate" (full hardware calibration every X minutes) to No Auto Cal  
e = SetField_int32(&calOptions, sgt_CalOptions /* -21 */, fldNum_CalOptions_AutoCalRate, 0L);  
  
// Set "CJC Calibration Rate" (cjc calibration for thermocouples every X minutes) to No Auto Cjc Cal  
e = SetField_int32(&calOptions, sgt_CalOptions /* -21 */, fldNum_CalOptions_CjcCalRate, 0L);
```