

instruNet version ≥ 1.4 is compatible with HP Vee. The instruNet to Hp Vee interface files and documentation reside at directory:

```
\ program files \ instruNet \ Application Software \ HPVee \
```

after installing instruNet ≥ 1.4 on a Windows computer. The Readme.txt file and the HpVee-iNet.doc files describe how to interface the two products. For more details, please see the Programming Application Notes and the instruNet User's Manual.

The interface files show two examples. One demonstrates how to read and write individuals instruNet channels, one number at a time; and the other shows how to digitize waveforms from instruNet channels.

The Scalar I/O Example Program Demonstrates:

- Reading an instruNet Channel (e.g. a voltage input)
- Writing to an instruNet Channel (e.g. a voltage output)
- Loading and closing the instruNet Driver
- Showing the instruNet Settings Window (i.e. instruNet World Network Page).
- Saving all instruNet channel settings in one 20KB array, storing this array to disk, and then restoring these settings after loading the array from disk.

The Oscilloscope Example Program Demonstrates:

- Digitizing several channels from instruNet and displaying the data, much like an oscilloscope.